

Spindle Hardware Instructions

This spindle hardware kit fits a variety of different applications. In some applications when the slotted nut is installed, the cotter pin hole will be located near the bottom of the slot (*see photo at right*). In these cases, to simplify the installation we suggest putting a slight bend towards the end of the cotter pin to allow it to clear the rotor hub and slide through the nut and spindle assembly. Once the cotter pin is through both sides of the nut, you may need to tap it flush to the slotted nut with a small punch before securing the cotter in place. *See pictures below.*

