

# #6466TCA-UK - Tubular Upper Control Arms Instructions for 1964-66 Ford Mustang

**Parts List:**

- 2 ea Upper Control Arm Assembly
- 4 ea 1/2-20x2-1/2 grade 8 Bolts
- 4 ea 1/2-20 grade 8 Lock Nuts
- 4 ea 1/2 Flat Washer

**Instructions:**

1. Remove the original upper control arms.
2. Install the new upper control arm assemblies. CPP recommends using new coil spring perches (part# 6267PCH-P).
3. Have the car professionally aligned.

**Notes:**

These control arms are 1/4" shorter than stock in order to provide a larger range of adjustment.

It may be necessary to shim the cross shafts.

The coil perch mount is slotted to accept both the rubber and PolyPlus type spring perches.

**GENERAL TORQUE SPECIFICATIONS:**

1/4"	grade 5	10lb/ft	1/4"	grade 8	14lb/ft
5/16"	grade 5	19lb/ft	5/16"	grade 8	29lb/ft
3/8"	grade 5	33lb/ft	3/8"	grade 8	47lb/ft
7/16"	grade 5	54lb/ft	7/16"	grade 8	78lb/ft
1/2"	grade 5	78lb/ft	1/2"	grade 8	119lb/ft
9/16"	grade 5	114lb/ft	9/16"	grade 8	169lb/ft
5/8"	grade 5	154lb/ft	5/8"	grade 8	230lb/ft

