



*Steering, Brake & Suspension Specialists*

## #6472RTCA-L, #6467RTCA-U & #6872RTCA-U - Instructions for 1964-72 GM "A" Body 4 Link Rear Trailing Arms

### Parts:

1 ea	Left Lower Control Arm Assembly
1 ea	Right Lower Control Arm Assembly
2 ea	Upper Control Arm Assemblies
4 ea	Lock-Out Plates
8 ea	1/2-13x4 Bolts
8 ea	1/2 Lock Washers
16 ea	1/2 Flat Washers
8 ea	1/2-13 Nuts

### Instructions:

1. Remove the coil springs.
2. Remove the original upper links.
3. Install the new upper links and lockout plates.
4. Remove the original lower links.
5. Install the new lower links. The anti-roll bar mounting tabs should be down, reward and inboard. If the anti-roll bar is being used install it now.
6. Install the coil springs.



**Lock Out Plate**



**Anti-Roll Bar Mount**

**Classic Performance Products, Inc.** 714.522.2000 | fax 714.522.2500  
378 E. Orangethorpe Ave. | Placentia, CA 92870 | [www.classicperform.com](http://www.classicperform.com)