



Steering, Brake & Suspension Specialists

#CP3100R - Hydraulic Brake Assist System Instructions

Universal Kit

Note:

This system is intended for "off road use only"

Instructions:

1. This system is for "advanced fabricators / master installers" only. If you are not highly experienced in automotive braking systems fabrication, results may be less than desirable, if not downright dangerous! Please do not attempt installation of this product if you are not comfortable with any aspect of this installation – enlist the services of a professional!
2. Please carefully inspect entire braking system thoroughly and replace any marginal items. Installation of braided steel, high performance brake lines and high performance brake fluid is highly recommended, though not mandatory.
3. This system is designed for use with 1970 and newer GM style master cylinders equipped with the "shallow style piston".
4. Please carefully inspect entire power steering system thoroughly and replace any marginal items. This system will not function properly unless the power steering system is 100%
5. Removal of the drivers seat greatly increases ease of kit installation and is highly recommended in some applications!
6. Disconnect battery.
7. Disconnect brake lamp switch electrical connector.
8. Disconnect brake pedal rod connection.
9. Remove existing power brake booster assembly if applicable.
10. Remove master cylinder attachment nuts and secure master cylinder approximately 8-10 inches forward of existing mounting, if brake line routing / integrity permits.
11. Installation of any power assist unit into a vehicle originally equipped with manual brakes may require adjusting the length of the brake lines to the master cylinder. In most cases, if the lines are in good shape, the brake lines can be carefully massaged to accommodate the revised master cylinder location.
12. Inspect master cylinder at this time for any signs of brake fluid seepage at rear seal and check for any sludge accumulation in fluid reservoirs. Replace master cylinder if necessary. This high output assist unit will fail a marginal master cylinder due to the higher levels of assist it is capable of generating!
13. Perform mock up of assist unit to firewall mounting, modify mounting plate as necessary to achieve secure mounting. This type of hydraulic assist unit can be mounted in either the "right side up or upside down" and will still function correctly.
14. Once firewall mounting has been established, determine the brake pedal rod connection needs and fabricate to suit. The installed pedal rod is threaded 3/8 NF.
15. After mounting and pedal rod configurations have been established, connect the master cylinder to hydraulic brake assist unit firmly.
16. At this time (once the brakes are bled and ready) it is highly recommended that you test your firewall and brake pedal pushrod fabrications by applying the brakes as hard as physically possible / reasonable to verify their integrities and proper functions.
17. Remove existing high side power steering line and completely drain system.
18. Fabricate and install a –6 AN style ps compatible pressure line to connect from the ps pump output fitting to the inlet of the hydraulic assist unit. (nearest port to the accumulator bottle)
19. Fabricate and install a –6 AN style ps compatible pressure line to connect from the outlet of the assist unit to the power steering system pressure inlet port.
20. Inspect existing power steering return line, replace if marginal.
21. Fabricate an additional low pressure fluid return fitting into the existing ps pump fluid reservoir, or cut existing power steering return line approximately 3 1/2 inches from pump fitting and install a brass "T" STRAIGHT INLINE for ps fluid return line circuit.
22. Connect a ps compatible low pressure return line to the return line fitting / nipple on the assist unit.
23. Route low pressure return line from assist unit to fluid return fitting of power steering pump or brass "T".
24. Verify that all prior steps have been successfully completed!
25. With engine off, fill power steering reservoir with high quality power steering fluid only. * Never use poor quality ps fluid or ATF because it foams in use causing noisy pump operation and erratic operation. Genuine GM PS fluid or equivalent recommended.
26. Reconnect battery and verify for proper brake light operations.
27. Disable ignition system and crank engine for five full seconds to initiate proper system priming.
28. Recheck fluid level topping off as necessary and crank engine for five more seconds. Repeat this procedure as necessary until fluid level remains consistent.
29. Cap fluid reservoir and restore ignition system operations.
30. Start engine briefly, check for any signs of fluid leakage. Do not depress brake pedal yet.
31. Shut engine off and recheck fluid level, topping off as necessary. Pump brake pedal a few times to purge any air trapped in the nitrogen reserve accumulator. If fluid appears foamy and pump operation was noisy in prior run sequence, allow vehicle to sit for 15 – 20 minutes.



Steering, Brake & Suspension Specialists

Hydraulic Brake Assist System Instructions (Continued)

32. Start engine, allow to warm up to full operating temperature.
33. With engine warmed up and idling, check for proper power steering operations and any leakage by steering vehicle from lock to lock approximately 5 full sweeps.
34. If all prior steps have been performed successfully, apply moderate pressure to brake pedal slowly 5 – 6 times. Shut engine off and recheck fluid level.
35. Start engine, apply full pedal pressure 2 or 3 times to verify proper systems integrities.
36. Carefully road test vehicle to verify proper operations and to get accustomed to the brake systems response.
37. Allow vehicle to sit overnight. Next day, when vehicle is still cold, recheck all connections and lines for proper torque, recheck fluid level and top off as necessary.

IMPORTANT! NEVER APPLY THE BRAKES WHILE THE MASTER CYLINDER IS REMOVED, OR YOU WILL DESTROY THE BRAKE ASSIST UNIT!

- Perform brake bleeding procedures with the engine off for best results.
- If supplied with the optional slip fit replaceable master cylinder pushrod, simply gently twist and pull the existing master cylinder pushrod out, then slip on the alternate rod by reversing the procedure. The longer rod will accommodate most 1969 and earlier “deep style” master cylinders, the shorter rod supplied standard will accommodate most 1970 and newer “shallow style” master cylinders.
- Please note: The high quality Aeroquip power steering linesets have adjustable end fittings! If the preset angles require adjustment, simply use two 11/16 wrenches to slightly change the fitting angles. The gap between the stationary hose nut on the line and the end fitting itself should not exceed more than the thickness of a penny, or leakage may occur.
- Please allow up to 500 miles of operation for the systems to fully “settle / break in”! Until all the air pockets and “micro bubbles” settle out of the assist unit and power steering system, operations may be initially noisy, accompanied by some “pedal kickback” upon braking, and “stiff / slow pedal return” caused by air in the systems.

PLEASE REFER TO OUR AEROQUIP LINE ASSEMBLY INSTRUCTIONS WHEN INSTALLING NEW LINE SETS.

Reprinted with permission from Hydratech Braking Systems. © Copyright Classic Performance Products, Inc. 2010 All Rights Reserved. This document may not be reproduced without prior written permission of CPP or Hydratech.

For technical help call Classic Performance Products Monday thru Friday 8:30am to 5:00pm at (714) 522-2000

Classic Performance Products, Inc. 714.522.2000 | fax 714.522.2500
175 E. Freedom Avenue | Anaheim, CA 92801 | www.classicperform.com