

#MCPV1 CPP Decal Instructions

Instructions:

Be sure your MCPV1 master cylinder lid is clean and free of any oily residue. Wipe clean with a lint-free micro fiber towel to avoid any scratches. A very small amount of brake cleaner in the recessed areas will help the decal stick better.



Remove the clear top film from the letters.



Peel the white protective backing from the decal and place the letters into the recessed areas on the master cylinder lid with the clear top film still on. Press down on the letters to help them stick onto the lid.

