



1940-1954 Chevy Pickup Power Brake Kit Install Sheet

1-866-925-1101

www.totalcostinvolved.com

**CHECK ALL PARTS INCLUDED IN THIS KIT TO THE PARTS LIST BEFORE INSTALLATING OF THE KIT.
IF ANY PIECES ARE MISSING, PLEASE CONTACT: TOTAL COST INVOLVED 800-925-1101**

1. Support the front and rear of the chassis on jack stands so that you will be able to install the brake kit from underneath. **Be safe!** Avoid pulling and pushing on the vehicle while it is off the ground.
2. Remove the old brake assembly and the cross member behind it. (Note that you will be removing the clutch pedal and this kit does not include one). To remove the rivets holding the cross member, grind the rivet heads flush. Center punch the rivet and drill through using progressively larger drills up to a 5/16" drill. The rivet should be relatively easy to punch out. If it is not, then continue drilling with a 3/8" drill.
3. Install the chassis bracket (the one with three parallel 90 degree bends) using four 7/16-20 x 1" bolts, washers and nyloc nuts. The bracket locates inside the frame rail with the top of the bracket under the top edge of the frame rail and uses the same holes as the original brake assembly.
4. From underneath the cab, slip the brake pedal through the firewall and attach the pivot-end to the booster bracket using the 1/2x20x1" bolt, large flat washer, and lock washer. Bolt the booster bracket on the chassis bracket using 3/8-24x1" bolts, washers, and nyloc nuts. The pedal pad can now be put on and locked down using the 1/2-20 jam nut.
5. Thread a 3/8-24 jam nut and heim joint onto the booster. Attach the booster to the booster bracket using the nuts and lock washers provided with the booster. Make sure you can get access to the vacuum inlet and that the studs for the master cylinder are orientated correctly.
6. Push the pedal up to its highest position without touching the firewall (a 1/4" gap will do fine) and adjust the heim on the booster until the holes line-up. Bolt together using the 3/8-24x 1-3/4 bolt and nyloc nut with the 3/8i.d.x .25" spacer in-between. It is important that you check that the pedal moves freely and returns to its highest position without being obstructed.
7. Bolt the master cylinder on using the remaining nuts and washers.
8. An access panel must be added to the floor to make filling the master cylinder with brake fluid easier. If you are making your own, mark the cut-out that you will be using on the underside of the floor above the master cylinder. Once marked, remove the master cylinder and booster to allow more room for cutting and working on the floor. Make sure you use a cover for the hole and that it is secured in place before covering it with your carpet

Parts:

(1) Chassis bracket	(4) 3/8-24x1" bolts	(1) 1/2x20 jam nut
(1) booster bracket	(1) 3/8-24x1-3/4" bolt	(1) 1/2 lock washer
(1) pedal	(5) 3/8-24 nyloc nuts	(4) 7/16-20 nyloc nuts
(1) booster	(4) 3/8" flat washers	(4) 7/16" flat washers
(1) master cylinder	(1) 3/8-24 jam nut	(1) 1/2-20x1" bolts
(1) 3/8 female heim joint	(1) 3/8" I.D.x.25" spacer	(1) 1/2 large flat washers
	(4) 7/16-20x 1" bolts	(1) booster nut/washer kit