

#6472RTDBL-TK - Installation Instructions


for 1964-72 Chevelle Rear Disc Brake Line Hose Tab Kit

Instructions:

1. Pass the tab over the end of the brake line.
2. Loosely attach the brake hose to the end of the brake line.
3. Position the tab so the 2 lower holes are on the inboard face of the shock mounting tab/rear arm pivot tab. Using the brake hose tab as a guide, drill 2 holes (1/4") into the shock tab.
4. Bolt the brake hose tab to the shock mounting tab.
5. Connect the other end of the hose to the caliper.
6. Tighten the brake hose to the brake line. Take care not to twist the brake hose.
7. With the hose positioned all the way into the brake hose tab, install the retaining clip onto the hose.




© Classic Performance Products, Inc. 2015
All rights reserved. This document may not be reproduced without prior written permission of CPP.



GENERAL TORQUE SPECIFICATIONS:

1/4"	grade 5	10lb/ft	1/4"	grade 8	14lb/ft
5/16"	grade 5	19lb/ft	5/16"	grade 8	29lb/ft
3/8"	grade 5	33lb/ft	3/8"	grade 8	47lb/ft
7/16"	grade 5	54lb/ft	7/16"	grade 8	78lb/ft
1/2"	grade 5	78lb/ft	1/2"	grade 8	119lb/ft
9/16"	grade 5	114lb/ft	9/16"	grade 8	169lb/ft
5/8"	grade 5	154lb/ft	5/8"	grade 8	230lb/ft

NOTE: With 18" and larger wheels we recommend 1/2" wheel studs. The larger the wheel diameter, the greater the force is on the wheel studs. Please inquire about replacement wheel stud kits available from CPP.



PLEASE NOTE: The installer needs to make sure that nothing can make contact with a brake hose, caliper, or other brake component at any point through the entire range of steering and suspension movement. The installer also needs to make sure none of the steering or braking components can become bound or jammed at any time through the range of suspension or steering movement.